






## INCRA TS-LS Positioner Only

### INCRA PARTS & COMPONENTS/ Table Saw Fence Systems



> Continued on next page for list of components.



LIST OF COMPONENTS:

ID#	PART NUMBER	NAME OF COMPONENT
1A	PLSP-700200	TSLS Base Assembly w/o Carriage - Imperial (1/32")
1B	PLSP-700200M	TSLS Base Assembly w/o Carriage - Metric (1mm)
2A	PLSP-700500	LS Carriage Assembly w/o Base - 32" Range
2B	PLSP-700500M	LS Carriage Assembly w/o Base - 810mm Range
3A	PLSP-700550	Imperial (1/32") Lead Screw w/ Mike Knob - 32" Range
3B	PLSP-700550M	Metric (1mm) Lead Screw w/ Mike Knob - 810mm Range
4	PLSP-400100	Red Steel Sub Base
5	PLSP-500100	Hairline Cursor Window
6	PLSP-500200	Plain Cursor Window
7	PLSP-500300	Clamping Pressure Adjusting Shims (Assorted)
8	PLSP-500400	Clamping Lever Bearing Pad
9	PLSP-400300	Leaf Spring Engager
10	PLSP-400200	Fence Mounting Bracket
11A	PLSP-800200	Imperial (1/32") Threaded Segment Replacement Kit
11B	PLSP-800200M	Metric (1mm) Threaded Segment Replacement Kit
12	PSCA-AC	Lexan Scale, Auto Centering
13	PSCA-1600S	Lexan Scale, 16"-0" (16" on the left, 0" on the right)
14	PSCA-3200SS	Stainless Steel Scale, 32"-0" w/Magnetic Tape
15	PSCA-4100M	Lexan Scale, 41-0cm (41cm on the left, 0cm on the right)
16	PSCA-8100MSS	Stainless Steel Scale, 81-0cm w/Magnetic Tape

**PLEASE REFER TO THE WEBSITE FOR THE LATEST PRICING.**

Refer to the part number(s) when ordering. To order, go to [www.incrementaltools.com](http://www.incrementaltools.com) or call 1-888-804-6272.